

Presentation Title

By Author

Date






Image Processing and Computer Vision Applications



Beth Israel Medical Center Improves MRI Accuracy



FLIR Accelerates Development of Thermal Imaging FPGA






Veoneer (Autoliv) Builds Radar Sensor using LiDAR-Based Verification




Image Processing Workflow


Access Data



Explore and Discover



Share Results




Iterate and Automate



Why Use MATLAB?


Ease of Use and Thorough Documentation




Need Technical Help?

- Technical Support
- Application Engineers

Rapid Prototyping and Algorithm Development





Code Generation for Embedded Deployment





Apps Accelerate Workflows





Color Thresholder App



Image Processing Toolbox & Computer Vision Toolbox

Import, Display, and Exploration

Camera Calibration and 3D-Vision

Geometric Transform and Image Registration

Tracking and Motion Estimation

Image Filtering and Enhancement

Feature Detection and Extraction

Image Segmentation and Analysis

LiDAR and Point Cloud Processing


3D Volumetric Processing


Deep Learning




3-D Image Processing Functions and Apps

Over 65 functions supported for 3-D volumetric data










Example: Segment Lungs from 3-D Chest Scan



Lidar and Point Cloud Processing





OpenCV Interface

- Bring OpenCV C/C++ code into MATLAB using MEX
- Ships with OpenCV-binaries (v3.4.0 as of 2018b)
- Large library of data type conversions
- Several examples to help get started

Install and Use Computer Vision Toolbox OpenCV Interface

R2019a

Use the OpenCV Interface files to integrate your OpenCV C++ code into MATLAB® and build MEX-files that call OpenCV functions. The support package also contains graphics processing unit (GPU) support.

- Installation
- · Support Package Contents
- · Create MEX-File from OpenCV C++ file
- Use the OpenCV Interface C++ API
- Create Your Own OpenCV MEX-files
- · Run OpenCV Examples

Installation


After you install third-party support files, you can use the data with the Computer Vision Toolbox™ product. Use one of two ways to install the Add-on support files.


- Select Get Add-ons from the Add-ons drop-down menu from the MATLAB desktop. The Add-on files are in the "MathWorks Features" section
- Type visionSupportPackages in a MATLAB Command Window and follow the prompts.



MATLAB with ADI ToF Camera

- ToF Camera makes it easy to find the hand
- MATLAB is used to figure out hand signal
- Demo: Rock, Paper, Scissors









NOTE: Additional toolboxes required are Image Processing, Computer Vision, and Image Acquisition




Step 1 – Detect the hand

 Grab image from camera depthMap = getsnapshot(depthVid);

 Convert to HSV color space, threshold, and clean up edges

```
hsv = rgb2hsv(depthMap);
BW = hsv(:,:,1) <= 0.25;
BW = imopen(BW,strel('disk',3));
BW = imfill(BW,'holes');</pre>
```









Step 2 – Measure hand, determine if fingers are extended

- Determine hand area, centroid, and convex hull
 - Convex hull allows us to find the fingersblobs = regionprops(BW,'Area','Centroid','ConvexHull');
- Determine if fingers are extended
 - Distance transform helps us estimate radius (green line)
 bwd = bwdist(~BW);
 radius = bwd(round(c(2)), round(c(1)));
 - Sub-select for the points outside 2*radius estimate (red line)
 d = sqrt((x-c(1)).^2+(y-c(2)).^2);

```
x((d - 2*radius)<0) = 0;
```











Step 3 – Count the number of fingers

- Eliminate points within 10 pixels of each other
- If no fingers, then it's "rock"
- If 1 finger, then it's "unclassified"
- If 2 fingers, then it's "scissors"
- If 3-5 fingers, then it's "paper"








Accelerate Calibration Workflow with cameraCalibrator

Steps

- Use checkboard printout with squares of a known size (29mm in this case)
- Load into CameraCalibrator app
- Press the calibration button
- Inspect results





Next Steps

- Use executable provided to try it yourself
- Download the code
- Evaluate MATLAB, Image Processing Toolbox, Computer Vision Toolbox, and Image Acquisition Toolbox

